



AGRILIGHT®



BETTER LIGHT, BETTER LIFE



# AGRIBOX pro

## Installation and user manual

Original manual V1.0

© Agrilight b.v. 2020



# Manual for the Installer and End-user

Dear Customer,

Thank you for purchasing the AGRIBOX pro. This manual contains all the information necessary to allow you to quickly familiarise yourself with the product. Please read this information carefully before using the product for the first time.

This manual is intended for both the installer and the end-user of the AGRIBOX pro. The table of contents allows you to find the information you need in the manual. We recommend that you perform the steps in the order described in this manual.

This is the original manual. Store the manual in a safe place!

For further information or to order manuals,  
please contact:

Agrilight  
Vlotlaan 643  
2681 TV  
Monster

Tel.: +31 (0) 174 287 287  
Fax: +31 (0) 174 287 292  
E-mail: [info@agrilight.nl](mailto:info@agrilight.nl)  
www: [www.agrilight.com](http://www.agrilight.com)

# Introduction

## Product description

### Intended use


The AGRIBOX pro is a light management system intended for automatic control of lighting luminaires. Any other form of use than that described above does not constitute an intended use. Agrilight B.V. cannot be held responsible for any injury or damage caused by the system being used incorrectly, unwisely or contrary to the intended use.

Agrilight B.V. gives the CE mark only to the AGRIBOX pro. The installer of the AGRIBOX pro is personally responsible for the electrical installation in accordance with the provisions of the law. Note that if the AGRIBOX pro becomes part of a larger system, this system as a whole must be qualified for the CE mark. Safety must be assured at all times so that the installer, the end-user and third parties can use the AGRIBOX pro safely.

## Registration

The type and serial number plate is attached to the AGRIBOX pro (fig. 1). Always include the type numbers of your luminaire when you contact your local Lely service provider or order spare parts. This information can be found on the production sticker.

1. Legal manufacturer
2. Production type manufacturer
3. Range connected power supply
4. Used current
5. Maximum used power consumption
6. Frequency range power supply
7. Ingress protection rate
8. Serial number
9. Manufacturing date month-Year
10. For markings, see manual



# Table of Contents

<b>1</b>	<b>Precautions and Safety Instructions</b>	<b>6</b>
<b>2</b>	<b>Symbols</b>	<b>6</b>
<b>3</b>	<b>Warranty</b>	<b>6</b>
<b>4</b>	<b>Technical Specifications</b>	<b>7</b>
4.1	General product specifications	7
4.2	Environmental influences	8
4.3	Tools required for the installer	8
<b>5</b>	<b>Most important parts</b>	<b>9</b>
5.1	AGRIBOX pro	9
5.2	Overview of touchscreen icons and most important screens	9
<b>6</b>	<b>Installation and Setup</b>	<b>11</b>
6.1	Draw up a lighting plan	11
6.2	Preparation for use: Installation and electrical connection	11
6.3	Installing the AGRIBOX pro	12
6.4	Installing the light sensor (IP65)	14
6.5	Electrical connection of the AGRIBOX pro	16
6.6	Setting up the AGRIBOX pro	18
6.7	Add a second AGRIBOX pro as slave	53
6.8	Prepare the AGRIBOX pro for 0 - 10 V luminaires	57
<b>7</b>	<b>Operation</b>	<b>59</b>
7.1	Switching a program on or off	59
7.2	Switching the groups on or off	61
7.3	Switching the control light program ON and OFF	65
<b>8</b>	<b>Maintenance and Maintenance Plan</b>	<b>67</b>
<b>9</b>	<b>Faults and Repairs</b>	<b>67</b>
<b>10</b>	<b>Disposal</b>	<b>67</b>
<b>11</b>	<b>WEEE</b>	<b>67</b>
<b>12</b>	<b>CE Declaration of Conformity</b>	<b>68</b>

# 1 Precautions and Safety Instructions

## DANGER

Danger! Keep the product away from water. If the electronic components come into contact with water, this can lead to an electric shock or even electrocution.

## WARNING

- Special know-how is necessary for assembly and installation so that only correspondingly qualified personnel should be entrusted to carry out this work.  
Assembly and installation must be performed in accordance with the local laws and regulations.
- Do not use the product if the product or cable is damaged.
- Disconnect the product from the power supply before starting installation or maintenance.
- Do not replace parts yourself. Consult a recognised maintenance fitter.
- The AGRIBOX pro contains electronic components that are sensitive to interference. Install the product out of the range of objects that can cause electrical interference, or if possible remove the objects that can cause electrical interference.
- Cordon off the working area for unauthorised persons during the installation.
- Wear the proper protective clothing during installation, such as working gloves, work shoes, helmet and protective overalls.

# 2 Symbols

In this user and installation manual, the following marking conventions have been used to draw attention to certain subjects or actions.

## DANGER

**Danger!** The life of the user is directly threatened.

## WARNING

**Warning!** The user can (seriously) injure himself or cause serious damage to the product. A warning indicates the injury to the user or the damage to the product if the user does not follow the procedures carefully.

## NOTICE

**Note!** A note contains supplementary information for the user. A note draws the user's attention to possible problems.

# 3 Warranty

Agrilight B.V. offers a warranty on production and material faults for a period of two (2) years from the original date of purchase of the product, on condition that the product is used only for its intended purpose. Any damage caused by abnormal use, improper handling, cleaning or negligence is not covered by this warranty. Agrilight B.V. gives no warranty on assembly and installation.

## 4 Technical Specifications

### 4.1 General product specifications

Product description	
Name:	AGRIBOX pro
Year of production:	2015
Manual version	08-2020
Technical specifications	
Voltage	100-240 V(AC) (-15% / +10%)
Frequency	50-60 Hz
Current	0.47 A @ 115 VAC / 0.28 A @ 230 VAC
Starting peak	55 A @ 115 VAC / 95 A @ 230 VAC
Power	20 W
Power factor	> 0.95
Mains supply voltage	3-core
DALI connection	2-core (galvanically separated)
Analog connection	0..10 V, max. 100 mA, galvanically separated, 2-pin
Red control light contact	Floating contact, for 230 VAC, max. 10 A
Screen signalling	Static connection, 3-core
Light sensor	0..10 V (3-core, screened)
Master/slave connector	Yes
Light groups	Max. 5
Timer programs	10
Number of DALI drivers	Max. 64
Dimmable	Yes (100% ~ +/- 10%)
IP degree of protection	IP65
Operating temperature	0°C ~ + 40°C (Ta)
Storage temperature	-20 °C ~ + 60 °C (Ta)
Relative humidity	40% ~ 90% (Ta)
Article dimensions (L x W x H)	240 x 194 x 85 mm
Packaging dimensions (L x W x H)	380 x 295 x 160 mm
Article weight	1.2 kg
Weight incl. packaging	1.4 kg
Supply cable diameter	8 - 13 mm
DALI cable diameter	2 x 1.5 mm <sup>2</sup> , not supplied
Cable for light sensor	3 x 0.34 mm <sup>2</sup> , screened
Connecting cable length	7 mm
Warranty (years)*	2

\* See Warranty terms

## 4.2 Environmental influences

The AGRIBOX pro may only be used indoors in livestock pens, agricultural buildings and sheds. The product must not be used in wet environments or outdoors. Use in other environments can influence the performance of the product or may damage the product.

## 4.3 Tools required for the installer



Screwdrivers  
(flat and cross-head)



Drill



Wire stripper




Luxmeter



# 5 Most important parts


## 5.1 AGRIBOX pro




### Parts list

1	Touchscreen	6	Washers
2	Mounting holes (4x)	7	Sealing plugs for the glands not used
3	Cover	8	Plugs
4	Light sensor	9	Screws
5	Glands		








## 5.2 Overview of touchscreen icons and most important screens



Start screen



Overview screen

Touchscreen icon	Description
	The corresponding function is switched OFF.
	The corresponding function is switched ON.
	The program is switched ON.
	Confirm an entered value.
	Delete the whole value.
	Backspace; delete the last character.
	<p>The function bar of a group:</p> <ul style="list-style-type: none"> <li>- OFF: The group is switched off.</li> <li>- Program: The program belonging to the group is switched on.</li> <li>- Manual: Manual operation of the group</li> </ul>

## 6 Installation and Setup

---

### WARNING

- Special know-how is necessary for assembly and installation so that only correspondingly qualified personnel should be entrusted to carry out this work.  
Assembly and installation must be performed in accordance with the local laws and regulations.
  - The AGRIBOX pro contains electronic components that are sensitive to interference. Install the product out of the range of objects that can cause electrical interference, or if possible remove the objects that can cause electrical interference.
  - Disconnect the product from the power supply before starting installation.
  - Cordon off the working area for unauthorised persons during the installation.
  - Wear the proper protective clothing, such as working gloves, work shoes, helmet and protective overalls.
- 

### 6.1 Draw up a lighting plan

Before you start to install the AGRIBOX pro, you should first consider carefully how you want to work in the building. Questions that you should ask yourself:

- Into how many groups do I want to divide the building?
- For how many hours are the luminaires to be switched on per group?
- For which groups do I want the light power to be adapted to the daylight?

Lay down your wishes in a lighting plan. Has the lighting plan been finalised and adopted? Then you are ready to install AGRIBOX pro.

### 6.2 Preparation for use: Installation and electrical connection

In order to prepare AGRIBOX pro for use, it must first be installed and the electrical connections made.

Only connect the luminaires with the AGRIBOX pro Switch. The AGRIBOX pro Switch can disconnect the installation from the mains power supply, e.g. for maintenance work.

Do you want to control more luminaires than the maximum number indicated in the specifications? Every time you exceed the maximum number, add an AGRIBOX pro Slave to an AGRIBOX pro Switch. If these products did not form part of your delivery, you can order them separately.

**NOTICE** If you use a light sensor, this should preferably be installed on the north side of the building. Set the light sensor dip switches in the 20 kLux position before calibration:  
Dipswitch 3 ON, Dipswitches 1,2 and 4 OFF.

## 6.3 Installing the AGRIBOX pro

### 6.3.1 Installing the glands

1. Separate the glands by unscrewing the lower part.



2. Place the upper side of the glands, including washers (figure right) in the right positions on the outside of the AGRIBOX pro.



3. Screw on the lower part of the glands on the inside of the AGRIBOX pro.

4. Press a sealing plug (figure right) into the glands that are not used.



### 6.3.2 Installing the AGRIBOX pro without brackets

1. Unscrew the plastic screws (4x) in anti-clockwise direction using a screwdriver.



2. Remove the cover.



- 
3. Remove the plastic seals from the mounting holes.



- 
4. Hold the product against the wall in the desired position and mark the mounting holes.
- 
5. Drill holes in the wall and insert plugs (the plugs are not supplied with the product).
- 
6. Fasten the product to the wall using screws (the screws are not supplied with the product).
- 
7. Place the plastic seals back in the mounting holes.



- 
8. Fit the cover again.

**NOTICE** Deliveries from January 2019 will contain a hinge for the cover.



- 
9. Tighten the plastic screws again in clockwise direction using a screwdriver.
- 

### 6.3.3 Installing the AGRIBOX pro with brackets

- 
1. Place the brackets onto the rear side of the AGRIBOX pro.



- 
2. Fasten the brackets to the AGRIBOX pro using the screws supplied.

Tighten the screws in clockwise direction using a screwdriver.



- 
3. Mark the desired positions for the brackets.
  4. Drill holes and insert the plugs supplied.
  5. Attach the brackets in the desired position using the screws supplied.

Tighten the screws in clockwise direction using a screwdriver.

---

## 6.4 Installing the light sensor (IP65)

- 
1. Unscrew the screws in anti-clockwise direction using a screwdriver.



- 
2. Remove the cover.



---


If you are above equator, the light sensor must be installed outside the barn on the north side.  
If you are below equator, the light sensor must be installed outside the barn on the south side.

**NOTICE** Install the sensor so that it has an unobstructed view, it is protected from direct sunlight and it is not near another light source.


- 
3. Hold the product in the desired position and mark the two mounting holes.
  4. Drill holes in the wall and insert plugs (the plugs are not supplied with the product).
  5. Fasten the product to the wall using screws (the screws are not supplied with the product).
  6. Loosen the glands in anti-clockwise direction.
-



- 
7. Pull a 3-core screened cable through the gland and connect it to the terminal:
- 1 UB +
  - 2 Ausg.
  - 3 GND



- 
8. Set the dip switches to the 20 kLux position:
- Dipswitch 1 OFF
  - Dipswitch 2 OFF
  - Dipswitch 3 ON
  - Dipswitch 4 OFF



**NOTICE** Default setting is 20 kLux. See paragraph 6.6.10.1 for more information.

- 
9. Tighten the glands on the master again in clockwise direction.
- 
10. Fit the cover again.
- 
11. Insert the screws into the product again and tighten in clockwise direction using a screwdriver.



## 6.5 Electrical connection of the AGRIBOX pro

The following parts have to be connected electrically in the AGRIBOX pro:

- Power supply
- Light sensor
- Control light
- Screen (optional)
- DALI (optional)
- Slave (optional, see section 4.5)


Proceed as follows:

- 
1. Unscrew the plastic screws (4x) in anti-clockwise direction using a screwdriver.

**NOTICE** Deliveries from January 2019 will contain a hinge. In this case, unscrew 2 screws.



- 
2. Remove the cover.




- 
3. Loosen one empty gland per connection in anti-clockwise direction.





- 
4. Pull the correct cable through the gland and connect it to the correct terminal:



1: Screen connection

Uppermost terminal (connector J5)

- + = floating contact
- - = floating contact

1.1: Push button (override "v" for main lights)

- Bottom connector
- Connection on the right side between IN2 and -

2: Light sensor 0-10V in connection

- 24V = UB+
- + = Ausg.
- - = GND
- SH = Shield

3: Slave/DSX connection

- See section 4.5.

4: Control light connection

- NO = Normally open contact
- COM = common


5: 0-10V OFF connection (suitable for luminaires with 0-10V control)

- + = 0-10V
- - = 0V

6: DALI connection

- DA = DALI connection
- DA = DALI connection

7: Power supply

- N = Neutral
- L = Phase
-  = Earth

- 
5. Tighten the glands again in clockwise direction.

- 
6. If applicable: Press the sealing plugs supplied into the gland holes that have not been used and tighten them in clockwise direction.

- 
7. Fit the cover again.

**NOTICE** Deliveries from January 2019 will contain a hinge. In this case, 2 screws must be connected.




- 
8. Tighten the plastic screws again in clockwise direction using a screwdriver.
-

## 6.6 Setting up the AGRIBOX pro


**NOTICE** The first time the AGRIBOX pro is switched on, the default language is English.

### 6.6.1 Set the language


1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.




2. Press 'SETTINGS'.




3. Press 'Language'.



- 
4. Press 'English'.




- 
5. Select the desired language by pressing the '<' or '>' button.  
Press 'Select' to confirm.




- 
6. Press 'Close' twice to return to the Start screen.
-

## 6.6.2 Set date and time

1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.




2. Press 'SETTINGS'.




3. Press 'Date & time' if this screen is not yet displayed.


Press on the time behind 'Set time'.




4. Enter the desired time and press the green button to confirm.




- 
5. Press on the date behind 'Set date'.




6. Enter the desired date and press the green button to confirm.



7. Press on the year behind 'Set year'.



8. Enter the desired year and press the green button to confirm.



9. Press 'Close' twice to return to the Start screen.
-


### 6.6.3 Set number of groups

With the AGRIBOX pro it is possible to divide the luminaires into groups. This allows you, for example, to switch off the luminaires in one part of the barn while leaving the luminaires in the rest of the barn switched on.


1. Draw up a plan where the luminaires are divided into groups. The lighting plan can be used for this.

**NOTICE** A maximum of 5 groups can be created in the AGRIBOX pro.


2. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.



3. Press 'SETTINGS'.




4. Press 'Settings'.






- 
5. Press on the number behind 'Number of groups'.



- 
6. Enter the desired number of groups and press the green button to confirm.



- 
7. Press 'Close' twice to return to the Start screen.
-


## 6.6.4 Add luminaires to the AGRIBOX pro

**NOTICE** All luminaires must be live before this step is carried out.


No luminaires are connected when the AGRIBOX pro is switched on for the first time. A luminaire has one or two drivers, each of which controls a row of LED lamps. Each driver has its own code. The luminaires are added as soon as the AGRIBOX pro reads in the codes.

### 6.6.4.1 Add all luminaires at once


1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.



2. Press 'SETTINGS'.




3. Press 'Search'.







- 
4. Press on the text behind 'Search mode'.




- 
5. Select 'Address -> All' by pressing the '<' or '>' button.  
Press 'Select' to confirm.



- 
6. Press on the text behind 'Find drivers'.




- 
7. Select 'Yes' by pressing the '<' or '>' button.  
Press 'Select' to confirm.  
The AGRIBOX pro now searches for all the drivers. The message 'Ready' appears when the search has been completed.




- 
8. Press 'Close' twice to return to the Start screen.
-

#### 6.6.4.2 Add a single luminaire at a later date


1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.




2. Press 'SETTINGS'.




3. Press 'Search'.




4. Press on the text behind 'Search mode'.





- 
5. Select 'Address -> New' by pressing the '<' or '>' button.  
Press 'Select' to confirm.



- 
6. Press on the text behind 'Search drivers'.



- 
7. Select 'Yes' by pressing the '<' or '>' button.  
Press 'Select' to confirm.  
The AGRIBOX pro now searches for the new drivers. The message 'Ready' appears when the search has been completed.




- 
8. Press 'Close' twice to return to the Start screen.
-

### 6.6.5 Divide luminaires into groups


**NOTICE** All luminaires must be on before this step is carried out.

A luminaire has one or two drivers, each of which controls a row of LED lamps. To divide the luminaires into groups, each driver has to be switched on manually. Then you have to determine visually in which group the LED lamps come on.


1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.



2. Press 'SETTINGS'.




3. Press 'Assign'.




- 
4. Press 'V' (ON) behind 'Driver 1' to switch on the corresponding lamp.


Find the luminaire whose lamp is switched on and determine to which group it belongs.




- 
5. Press on the text behind 'Driver 1' (under 'Group').



- 
6. Select the desired group by pressing the '<' or '>' button.  
Press 'Select' to confirm.



- 
7. Press 'X' (OFF) behind 'Driver 1' to switch off the corresponding lamp.



- 
8. Repeat steps 3 to 7 for all the other driver.

**NOTICE** These steps can take some time.

Press 'Close' twice to return to the Start screen.

---




### 6.6.6 Set lighting programs

A lighting program allows you to switch the luminaires on and off within a period of 24 hours at the times desired by you. A total of 10 lighting programs can be set. 8 times can be set per lighting program.

Example:

From 6:00 until 21:30 the group of luminaires will illuminate the barn for 100%. When a light sensor is present, the group of luminaires will turn off when the light from outside is enough to illuminate the inside of the barn. The group of luminaires must then switch off. Enter the times as follows:



PROGRAM 1	PROGRAM 2	PROGRAM 3	PROGRAM 4	NEXT	CLOSE
1	5:30	0 %	5	0:00	0 %
2	6:00	100 %	6	0:00	0 %
3	21:30	100 %	7	0:00	0 %
4	22:00	0 %	8	0:00	0 %


- Time 1: The group of luminaires switches on at 5:30 a.m.
- Time 2: From 5:30 a.m. until 6:00 a.m. the light power is gradually increased up to 100%.
- Time 3: From 6:00 a.m. until 21:30 p.m. the group of luminaires remains switched on at 100%.
- Time 4: From 21:30 p.m. until 22:00 p.m. the light power is gradually decreased down to 0%.

Times 5 to 8 can be entered if you wish for the group of luminaires to be switched on and off at several times.


**NOTICE** The first and last time must always be 0%. If this is not the case, the luminaire will remain switched on.

A lighting program is set as follows:

1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.




2. Press 'PROGRAM'.




3. Press the desired program.


Press on the time behind '1'.




4. Enter the desired starting time and press the green button to confirm.



- 
5. Press on the percentage (%) behind '1'.



- 
6. Enter the percentage with which the lamps are to be switched on at this time and press the green button to confirm.



- 
7. Repeat steps 4 to 7 for the other required times.

When all the times have been entered, program 1 is set.

- 
8. If necessary, repeat steps 3 to 8 for the other programs.

**NOTICE** A maximum of 10 programs can be set.

- 
9. Press 'Close' twice to return to the Start screen.
-




### 6.6.7 Set control light


Four control lights program can be set. The control light is less strongly perceived by the animals. The animals are therefore not disturbed in their day and night rhythm.

Set the control light program as follows:

1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.



2. Press 'PROGRAM'.



3. Press 'NEXT' twice.




4. Press 'CONTROL'.


Press on the time behind '1 ON:'.




- 
5. Enter the desired starting time and press the green button to confirm.



- 
6. Press on the time behind '1 OFF:'.



- 
7. Enter the desired end time and press the green button to confirm.



- 
8. If necessary, repeat steps 5 to 7 for the other times.


**NOTICE** A maximum of 4 times can be set for switching the control light on and off.

- 
9. Press 'Close' twice to return to the Start screen.
-


### 6.6.8 Add a lighting program to a group

1. Press the gear wheel in the top right-hand corner of the Start screen.

The overview screen is displayed.




2. Press 'GROUPS'.




3. Select one of the desired groups at the top of the screen.

Press on the text behind 'Select Light program'.



4. Select the desired program by pressing the '<' or '>' button.  
Press 'Select' to confirm.

The desired program is now added to the selected group.




5. If necessary, repeat steps 3 to 5 to add programs to other groups.
6. Press 'Close' twice to return to the Start screen.


### 6.6.9 Remove a luminaire from the AGRIBOX pro system

1. Remove the luminaire from the livestock pen/shed/agricultural building.


2. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.




3. Press 'SETTINGS'.




4. Press 'Search'.




- 
5. Press on the text behind 'Search mode'.



- 
6. Select 'Search' by pressing the '<' or '>' button.  
Press 'Select' to confirm.




- 
7. Press on the text behind 'Search drivers'.



- 
8. Select 'Yes' by pressing the '<' or '>' button.  
Press 'Select' to confirm.

The AGRIBOX pro searches for drivers that are still installed in the system. The message 'Ready' appears when the search has been completed.

The number of drivers removed is deducted from the AGRIBOX pro system.



- 
9. Press 'Close' twice to return to the Start screen.
-



## 6.6.10 Set light values

**NOTICE** You need a luxmeter for these operations.

### 6.6.10.1 Activate daylight compensation

**NOTICE** We recommend that this operation is not carried out in the middle of the day.


Daylight compensation can be set if the light sensor is installed. A certain light level has to be achieved in the area with the luminaires. Daylight can shine in and thus influence the light level. The light sensor detects the amount of daylight and feeds this information back to the AGRIBOX pro. The AGRIBOX pro then activates the luminaires in order to achieve the desired light level.

No luxmeter available? Take 10% of the value measured by the light sensor (this value can be found under “Calibration light outside”) and enter this figure for “Calibration light inside”.

1. Open the cover of the light sensor.




2. Set the dip switches to the 20 kLux position. This is the default setting when delivered:
  - Dip switch 1 OFF
  - Dip switch 2 OFF
  - Dip switch 3 ON
  - Dip switch 4 OFF




Now go to the touchscreen:


3. Press 'SETTINGS'.



- 
4. Press 'Settings'.




- 
5. Press on the text behind 'Daylight sensor'.




- 
6. Select 'Yes' by pressing the '<' or '>' button.

Press 'Select' to confirm.


The daylight sensor is switched on.  
A number of values to be set appear under 'Daylight sensor'.



- 
7. Press the two 'down' arrows until 'Calibration light outside' appears on the screen.




8. Press on the value behind 'Calibration light outside'.




9. Press the green button to confirm.

The light sensor automatically calculates the amount of daylight (in lux). When confirmed, this value is stored in the system.




10. Press on the value behind 'Calibration light inside'.

**NOTICE** Measure the number of lux at various points in the barn with a luxmeter and take an average.



11. Enter the actual measured value for the calibration light inside and press the green button to confirm.





- 
- 11 a. “Maximum light inside” is meant to be the average light level what you can reach when all the lights are on for 100%.


The default setting is 200 lux in newly delivered control boxes.

Press on the value next to “Maximum light inside” and change this into the value which is the average (Eav) lux level from the light plan.

When using a combination of AGRILED® luminaires, then use the highest average (Eav) value from the light plan.


Setting range Maximum light inside is between 50 until 9999 lux.

This value is the Eav (lx). from the light plan.




- 
12. Press on the arrow downwards and press on the text “Response delay”.

If the daylight in the barn is reduced for a brief time (for example due to a cloud), the AGRIBOX pro can switch on the luminaires after a certain time. This is the response delay.



- 
13. Enter the desired value (in minutes) and press the green button to confirm.

In the figure, the AGRIBOX pro switches on the luminaires as soon as there has been less light in the barn for 10 minutes.



---

Calibration complete?

14. Calculate and set the light sensor range:  
Use the table below to calculate the correct light sensor range. Set the range in the sensor by dip switches and in the Control box by adjusting the setting “Measurement range sensor”

A = Actual measured lux level outside



B = Calibration lux level light outside (see manual chapter 6.6.10.1.7 – 6.6.10.1.9)





C = Calibration Lux level light inside (see manual chapter 6.6.10.1.1 and 6.6.10.1.10 – 6.6.10.1.11)

D = Average light level when light is 100% on in the barn (Eav. light plan)

E = Measurement range light sensor, the sensor can't measure above this value

F = Minimum Lux level light sensor. Below shown value, measured light level is 0



Calculation setting light sensor	Measurement range settings AGRIBOX pro (E)	Dipswitch settings in light sensor	Minimum value (F)
$B/C * D = < 2.000 \text{ lux}$	2.000 Lux	2.000 Lux 	30 Lux
$B/C * D = \text{between } 2.000 \text{ and } 5.000 \text{ lux}$	5.000 Lux	5.000 Lux 	75 Lux
$B/C * D = \text{between } 5.000 \text{ and } 20.000 \text{ Lux}$	20.000 Lux	20.000 Lux 	300 Lux
$B/C * D = \text{between } 20.000 \text{ and } 60.000 \text{ lux}$	60.000 Lux	60.000 Lux 	900 Lux


Example  $(300/50) * 180 = 1.080 >$  In this case the sensor setting is 2.000 Lux and software setting is 2.000 Lux.

---


15. Close the cover of the light sensor.

---

16. Press the two 'down' arrows until 'Measurement range sensor' appears on the screen.



17. Press on the value next to 'Measurement range sensor'.



18. Select the calculated range for the light sensor in chapter 6.6.10.1.14 by pressing the '<' or '>' button.

Press 'Select' to confirm. The measuring range of the light sensor is now set to the calculated value.

**NOTICE** Do NOT adjust the 'Sensor darkness value' manually. The sensor's darkness value is automatically adjusted when the value of the 'Measurement range sensor' is changed.


19. Press 'Close' twice to return to the Start screen.

---


### 6.6.10.2 Activate or deactivate daylight compensation per group

Daylight compensation means that the light is automatically regulated by the light sensor

1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.




2. Press 'GROUPS'.



3. Press the desired group at the top of the screen.


Press on the text behind 'Daylight compensation'.

**NOTICE** Default setting is "yes".



4. Perform one of the following actions:
  - Select 'Yes' by pressing the '<' or '>' button. Daylight compensation is switched on.
  - Select 'No' by pressing the '<' or '>' button. Daylight compensation is switched off.

Press 'Select' to confirm.




5. If necessary, repeat steps 4 and 4 for the other groups.
6. Press 'Close' twice to return to the Start screen.


### 6.6.10.3 Switch on screen compensation

Screen compensation can be set if an automatic screen/curtain is installed. There is a possibility to connect a contact of this screen/curtain to the AGRIBOX pro. When the screen/curtain is closed, there is less light in the barn. With this setting, the lights will be increased when the screen/curtain is closed.


1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.




2. Press 'SETTINGS'.



3. Press 'Settings'.




4. Press the two 'down' arrows repeatedly until 'Screen' appears on the display.






- 
5. Press on the text behind 'Screen'.




- 
6. Select 'Yes' by pressing the '<' or '>' button.

Press 'Select' to confirm.

Screen compensation is switched on.  
'Screen compensation' is displayed.




- 
7. Press on the value behind 'Screen compensation'.



- 
8. Enter the percentage of daylight to be blocked by the screen. You can find this out from the supplier of the screen cloth.

In the figure on the right, 20% of the daylight is blocked.


Press the green button to confirm.




- 
9. Press 'Close' twice to return to the Start screen.
-

#### 6.6.10.4 Activate or deactivate screen compensation per group

1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.




2. Press 'GROUPS'.




3. Press the desired group at the top of the screen.

Press on the text behind 'Screen compensation'.



4. Perform one of the following actions:
  - Select 'Yes' by pressing the '<' or '>' button. Screen compensation is switched on.
  - Select 'No' by pressing the '<' or '>' button. Screen compensation is switched off.

Press 'Select' to confirm.




5. If necessary, repeat steps 4 and 4 for the other groups.
6. Press 'Close' twice to return to the Start screen.




### 6.6.10.5 Activate or deactivate the daylight sensor


1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.




2. Press 'SETTINGS'.



3. Press 'Settings'.




4. Press on the text behind 'Daylight sensor'.



- 
5. Perform one of the following actions:
- Press the '<' or '>' button and select 'Yes' to activate the daylight sensor.
  - Press the '<' or '>' button and select 'No' to deactivate the daylight sensor.

Press 'Select' to confirm.


**NOTICE** Default setting is "yes".




- 
6. Press 'Close' twice to return to the Start screen.
- 

### 6.6.11 Set brightness of the display


- 
1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.



- 
2. Press 'SETTINGS'.




- 
3. Press 'Settings'.




- 
4. 'Display brightness' appears on the screen.

- 
5. Press on the percentage (%) behind 'Display brightness'.



- 
6. Enter the desired percentage brightness of the display and press the green button to confirm.




- 
7. Press 'Close' twice to return to the Start screen.
-

## 6.6.12 Factory settings and operating hours


### 6.6.12.1 Reset the displayed time that a group has been in operation

As soon as a program belonging to a group is switched on, the number of hours and minutes that the group is (has been) in operation is displayed. To reset the time, proceed as follows:


1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.




2. Press 'GROUPS'.



3. Press the selected group at the top of the screen.  
  
Press on the time behind 'Operating hours'.



4. Press the circle with the cross and then press the green button to confirm.  
  
The time that a group has been in operation is now reset.




5. Press 'Close' twice to return to the Start screen.


### 6.6.12.2 Reset the AGRIBOX pro to the factory settings

**⚠ WARNING** When the following steps are performed, all settings are deleted and reset to the factory settings.

1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.



2. Press 'i' in the top right-hand corner of the Overview screen.



3. Press 'Restore' behind 'Restore factory settings'.  
A warning is displayed.



4. Press 'YES'.  
The AGRIBOX pro is now reset to the factory settings





## 6.7 Add a second AGRIBOX pro as slave

Two additional AGRIBOX pro's can be added to the AGRIBOX pro in order to be able to control more luminaires. These extra AGRIBOX pro's are an extension of the first AGRIBOX pro. This means that they cannot be set independently and only perform what the first AGRIBOX pro dictates. The first AGRIBOX pro is therefore the master and the other AGRIBOX pro's are slaves.


### 6.7.1 Electrical connection of the slave

1. Determine which AGRIBOX pro is the master and which the slave(s).
2. Assemble the second AGRIBOX pro. See section (6.3) for further information.

3. Unscrew the plastic screws (4x) on both AGRIBOX pro's in anti-clockwise direction using a screwdriver.




4. Remove the covers.



5. Loosen an empty gland on the master in anti-clockwise direction.

6. Pull a 3-core cable through the gland on the master and connect it to the DSX terminal (3):  
DSX +  
DSX -  
DSX SH

Move jumper JP5 to the 'down' position by placing the red cap over the bottom two pins.




7. Move jumper J12 to the 'down' position by placing the red cap over the bottom two pins. This determines that this AGRIBOX pro is the master.



8. Turn rotary switch S1 of the master (in the top left-hand corner of the circuit board) to 1.

Turn rotary switch S2 of the master (in the top left-hand corner of the circuit board) to 0. This sets the code for the master to 01.


**NOTICE** This number code must not be 00!



9. Tighten the glands on the master again in clockwise direction.
10. Loosen an empty gland on the slave in anti-clockwise direction.

11. Pull a 3-core cable through the gland on the slave and connect it to the DSX terminal (3):  
DSX +  
DSX -  
DSX SH

**NOTICE** Connect the same cables in the master to the same connection in the slave.



Move jumper JP5 to the 'down' position.

12. Move jumper J12 to the 'up' position to indicate that this AGRIBOX pro is the slave.


13. Turn rotary switch S1 of the first slave (in the top left-hand corner of the circuit board) to 2.

Turn rotary switch S2 of the first slave (in the top left-hand corner of the circuit board) to 0.

This sets the code for the slave to 02.

**NOTICE** This number code must not be 00!


The code must be entered in the master.  
See section 6.7.2.




	Jumper JP5	Jumper J12	Rotary switch S2	Rotary switch S1
Master	Down	Down	0	1
Slave 1	Down	Up	0	2
Slave 2	Down	Up	0	3
Slave 3	Down	Up	0	4

### 6.7.2 Set the slave


1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.




2. Press 'SETTINGS'.



3. Press 'Settings'.




4. Press the two 'down' arrows until 'Number of DALI circuits' appears on the screen.




5. Press on the number behind 'IO address DALI circuit 2'.

The AGRIBOX pro recognises the amount of slaves connected




6. Enter the code for the slave and press the green button to confirm.

See section 6.7 for further information on the code for the slave.




7. 'IO address DALI circuit 3' is displayed; the second slave can be added here. 'Assign 2' is also displayed at the top of the screen.

Press 'Assign 2'.



8. Add the new luminaires to the slave. See section 6.6.4 for further information.



9. Press 'Close' twice to return to the Start screen.


## 6.8 Prepare the AGRIBOX pro for 0 - 10 V luminaires

The basis of the AGRIBOX pro is a DALI steering signal. In the market there are also 0-10V luminaires available. With this setting, you can connect these kind of luminaires to the AGRIBOX pro.


For the electrical connection of 0-10 V luminaires, refer to section 4.3.

Proceed as follows to set the 0-10 V luminaires in the AGRIBOX pro:


1. Press the gear wheel in the top right-hand corner of the Start screen.  
The overview screen is displayed.



2. Press 'SETTINGS'.




3. Press 'Settings'.







4. Press the two 'down' arrows until 'Dalibus control signal' appears on the screen.




5. Press 'dalibus'.



6. Select '0-10V' by pressing the '<' or '>' button.  
Press 'Select' to confirm.



7. The AGRIBOX pro is now ready for 0-10 V luminaires.



8. Press 'Close' twice to return to the Start screen.


## 7 Operation

### 7.1 Switching a program on or off

Switch on



1. **NOTICE** Ensure that you see the Start screen.

Press the clock icon behind 'ON/OFF' if it has not yet been selected.



2. Press alongside 'Program' in the bar under the desired group(s).  
The set program for the selected group is switched on.

A percentage value is displayed, indicating the percentage at which the LED lamps in the luminaire are on.








## Switch off

1. **NOTICE** Ensure that you see the Start screen.

Press the clock icon behind 'ON/OFF' if it has not yet been selected.



2. Press alongside 'OFF' in the bar under the desired group(s).  
The set program for the selected group is switched off.



## 7.2 Switching the groups on or off



### 7.2.1 Switch all groups on or off at once

Switch on

**NOTICE** Ensure that you see the Start screen.

Press the 'V' icon behind 'ON/OFF'.

All the luminaires are switched on at 100%.





## Switch off

**NOTICE** Ensure that you see the Start screen.

Press the 'X' icon behind 'ON/OFF'.

All the luminaires are now switched off.




## 7.2.2 Switch a single group on or off

### Switch on


1. **NOTICE** Ensure that you see the Start screen.

Press the clock icon behind 'ON/OFF' if it has not yet been selected.




- 
2. Press alongside 'Manual' in the bar under the desired group(s).


A percentage value is displayed, indicating the percentage at which the LED lamps are on.



3. Press on the percentage value.




4. Select the desired light level by pressing the '<' or '>' button.  
Press 'Select' to confirm.  
The group is switched on with the selected light level.



## Switch off


1. **NOTICE** Ensure that you see the Start screen.

Press the clock icon behind 'ON/OFF' if it has not yet been selected.



2. Press alongside 'OFF' in the bar under the desired group(s).

The group switches off.





## 7.3 Switching the control light program ON and OFF

### Switch on - method 1

**NOTICE** Ensure that you see the Start screen.

Press the 'V' icon behind 'CONTROL LIGHT'.

All control lights are switched on.




### Switch on - method 2

**NOTICE** Ensure that you see the Start screen.

Press the clock icon behind 'CONTROL LIGHT' if it has not yet been selected.

The control lights are switched on according to their respective program.







## Switch off

**NOTICE** Ensure that you see the Start screen.

Press the 'X' icon behind 'CONTROL LIGHT'.

All the control lights are now switched off.



## 8 Maintenance and Maintenance Plan

- **⚠ WARNING** Disconnect the product from the power supply before starting maintenance.
- Clean the AGRIBOX pro with a dry or slightly damp cloth.
- Do not use abrasive cleaning agents.
- Do not use caustic cleaning agents or products with bleach.
- Consult a cleaning specialist if the AGRIBOX pro is heavily soiled.
- Store the product in a dry and dust-free place.

## 9 Faults and Repairs

**⚠ WARNING** Do not replace parts yourself. This would void the warranty.

**NOTICE** Please contact your local dealer if the product does not function or the electronics are defective.

## 10 Disposal

Disposing this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling.

Decommissioning and disassembly of the product can be dangerous and must be done only by qualified recycling organizations. All components must be disposed in compliance with the local rules and regulations.

Contact your local authority for further details

## 11 WEEE



This symbol [crossed-out wheel bin WEEE] indicates separate collection of electrical waste and electronic equipment in the European countries. We are committed to being a good corporate citizen. As part of that commitment, we strive to maintain an environmentally conscious manufacturing operation

In accordance with the European Union WEEE (Waste Electrical and Electronic Equipment) Directive 2012/19/EC, we would like to notify you that this product might contain regulated materials, which upon disposal, according to the WEEE directive, require special reuse and recycling processing.

Additional local legislation may apply.

**NOTICE** Only this product itself falls under the WEEE Directive. When disposing of packaging and other related shipping materials we encourage you to recycle these items through the normal channels.

# 12 CE Declaration of Conformity



Address : H&F Electronics B.V.  
Rijnaakkade 5, 5928 PT, Venlo  
P.O. Box 3164, 5902 RD, Venlo  
Tel : + 31 (0)77 323 12 00  
Mail : [info@hf-electronics.com](mailto:info@hf-electronics.com)

## EC Declaration of Conformity

CE-DECLARATION OF CONFORMITY  
CE-VERKLARING VAN OVEREENSTEMMING  
DÉCLARATION DE CONFORMITÉ CE  
CE-Konformitätserklärung  
CE-ДЕКЛАРАЦИЯ ЗА СЪОТВЕТСТВИЕ  
PROHLÁŠENÍ O SHODĚ CE  
EF-overensstemmelseserklæring  
CE märgis – vastavastatustunnustus  
CE-DECLARACIÓN DE CONFORMIDAD  
CE-VAAITUMUSTENMUKAISUUSVAKUUTUS  
CE IZJAVA O SKLADNOSTI  
EK-MEGFELELŐSÉGI NYILATKOZAT  
CE-samræmisýfirlýsing  
DICHIARAZIONE DI CONFORMITÀ CE  
EB ATTIKTIES DEKLARACIJA  
CE ATBILSTĪBAS DEKLARĀCIJA  
DEKLARACJA ZGODNOŚCI CE  
DECLARAȚIE DE CONFORMITATE CE  
FÖRSÄKRAN OM ÖVERENSSTÄMMELSE CE-MÄRKNING  
VYHLÁŠENIE O ZHODE CE  
IZJAVA O SKLADNOSTI CE  
Declaração CE de Conformidade



The undersigned, representing the following supplier  
Ondergetekende, vertegenwoordiger van de volgende leverancier  
Le soussigné, représentant le fournisseur suivant  
Der Unterzeichnete, den folgenden Lieferanten vertretend  
Долгоподписант, представляющ следния доставчик  
Niže podpisani v zastoupení následujícího dodavatele  
Undertegnede, som repræsenterer nedenstående leverandør  
Allakirjutanu, kes esindab alljärgnevat tarnijat  
El abajo firmante, en representación del siguiente proveedor  
Allekirjoittanut, joka edustaa seuraavaa toimittajaa  
Dojle potpisani, kao predstavnik dobavljača  
Alulírott, aki a következő beszállítót képviseli  
Undirritaður sem er fulltrúi eftirfarandi birgis  
La firmataria, che rappresenta il seguente fornitore  
Pasirašęs asmuo, atstovaujantis toliau nurodytam tiekėjui  
Apakšā parakstījusies persona, kas pārstāv piegādātāju  
Niżej podpisany, reprezentujący następującego dostawcę  
Subsemnatul, reprezentând furnizorul următor  
Undertecknad, som representerar följande leverantör  
Nižle podpisani v zastoupení následujícího dodavatele  
Podpisani predstavnik dobavitelja  
abaixo-assinado, em representação do fornecedor

H&F Electronics B.V.  
Rijnaakkade 5  
5928PT Venlo  
Netherlands

Products  
Producten  
Produits  
Produkte  
Продукти  
Výrobky  
Produkter  
tooted  
Productos  
Tuotteet  
Proizvodi  
Termékek  
Vörur  
Prodotti  
Gaminiai  
produkti  
Produkty  
Produse  
Produkter  
Výrobky  
Za naslednje izdelke  
Produtos

Lighting Management system with Dali

Type number  
Typenummer  
Numéro de type  
Nummer eingeben  
Введете номер  
Číslo typu  
Type nummer  
Tüübi number  
Teclea un número  
Tyypinnumero  
Unesite broj  
Típuszám  
Tegundamüner  
Digita il numero  
Tipo numeris  
Vēlāda numuru  
Wpisz numer  
Introduccij numāru  
Typnummer  
Zadajte číslo  
Številka tipa  
Número do tipo

- LMS-30-000
- LMS-31-000
- LMS-32-000
- LMS-33-000

Hereby certifies that this product is conform with the European standards.

Verklaart hierbij dat dit product voldoet aan de Europese normen

Certifie par la présente que ce produit est conforme aux normes européennes.

bestätigt hiermit, dass dieses Produkt den europäischen Normen entspricht.

С това се удостоверява, че този продукт отговаря на европейските стандарти

tímto potvrzuje, že tento výrobek je v souladu s evropskými normami

bekræfter hermed, at dette produkt er i overensstemmelse med de europæiske standarder

kinnitab klæsolevage, et see toode vastab Euroopa standarditele

Certifica por la presente que este producto satisface las normas europeas

todistata, että tämä tuote on eurooppalaisien standardien mukainen

Ovime se potvrđuje da je ovaj proizvod sukladan evropskim standardima

Ezennel igazolja, hogy ezek a termékek megfelelnek az európai szabványoknak

Hér með vottað að þessi vara er í samræmi við evrópska staðla

Dichlara che il prodotto è conforme alle norme europee

Patvirtina, kad gaminiai atitinka Europos Sąjungos standartus

ar šio apšpecina, ka produkti atbilst Eiropas standartiem

Niniejszym oświadczam, że produkt ten jest zgodny z normami europejskimi

Certifica que este produto está em conformidade com as normas europeias

Intygat härmed att denna produkt uppfyller kraven i de europeiska standarderna

týmto potvrđuje, že tento výrobek je v súlade s evropskými normami

Potvrjujem, da je ta izdelek skluden z evropskimi standardi

Certific prin prezenta că acest produs este conform cu standardele europene

- LVD 2014/35/EU
- EMC 2014/30/EU
- RoHS 2011/65/EU

References to the relevant harmonised standard used to which conformity is declared

Verwijzingen naar de desbetreffende geharmoniseerde norm waarnaar conformiteitsverklaringen worden gebruikt

Références à la norme harmonisée pertinente utilisée à laquelle la conformité est déclarée

Verweise auf die jeweils verwendete harmonisierte Norm, für die die Konformität erklärt wird

Позовавания на съответния хармонизиран стандарт, използван за деклариране на съответствието

Odkazy na příslušnou harmonizovanou normu, pro kterou je shoda deklarována

Henvísninger til den relevante harmoniserede standard, som anvendes til hvilken overensstemmelse er angivet

lited vastavale õhtlustatud standardile, millele vastavus on deklareeritud

Referencias a la norma armonizada correspondiente utilizada para la cual se declara la conformidad

Vittaukset sovellettuun yhdenmukaistettuun standardiin, jolle vaatimustenmukaisuus on ilmoitettu

Upudvanje na relevantne uskladene norme na koje se prijavljuje skladnost

Hivatkozás a vonatkozó harmonizált szabványra, amelyre a megfelelést bejelenti

Tilvísanir í viðeigandi samhæfða staðalinn sem notaður er til að samræmingu sé lýst

Riferimenti alla norma armonizzata pertinente con cui viene dichiarata la conformità

Nuorodos į taikomą darnąjį standartą, kuriame deklaruojama atitiktis

Atsauces uz attiecīgo saskaņoto standartu, kam deklarēta atbilstība

Odniesienia do odpowiedniej normy zharmonizowanej, w odniesieniu do której deklarowana jest zgodność

Referências à norma harmonizada relevante à qual a conformidade é declarada

Trimitiri la standardul armonizat relevant pentru care se declară conformitatea

Hánvísningar til den relevantu harmoniseraða standarden som anvínds för vilken överensstämmelse deklarerats

Odkazy na příslušnou harmonizovanou normu, na které se deklaruje shoda

Sklacevanja na uporabljeni ustrezni usklajeni standard, za katerega je navedena skladnost

- EN-IEC 61010-1:2010
- EN-IEC 61347-1:2015
- EN-IEC 61347-2-13:2014/A1:2017
- EN 55015:2013/A1:2015
- IEC 61000-3-2:2018
- IEC 61000-3-3:2013/A1:2017
- EN-IEC 61547:2009
- EN 50581:2012

Signature & date

Handtekening & datum

Signature & date

Unterschrift & Datum

Подпис & Дата

Podpis & datum

Underskrift & dato

Allkiri & Kuupäev

Firma & Fecha

Allekirjoitus & Pvm

Potpis & Datum

Aláírás & Dátum

Undirritun & dagsetning

Firma & data

Parašas & data

Paraksts & datums

Podpis & data

Semnătura & data

Underskrift & Datum

Podpis & datum

Podpis & datum

Assinatura & data

H.J.M. Hovens  
Managing Director  
H&F Electronics B.V.



17-01-2019







# AGRILIGHT®



BETTER LIGHT, BETTER LIFE

Agrilight b.v.  
Vlotlaan 643  
2681 TZ Monster  
The Netherlands  
+31 (0)174 287 287  
[www.agrilight.com](http://www.agrilight.com)  
[info@agrilight.com](mailto:info@agrilight.com)

